—. Install QPST2.7

Document path:

https://www.asuswebstorage.com/navigate/s/680137D3EF584B43B8D5AEC449CB0A0BY or in Tuserhp.com

- 1 unzip qpst.win.2.7_installer_00471.4
- 2 Click QPST.2.7.471.exe



3 The program will remind need to install VC++2013, click install

status	Requirement
'ending	VC++ 2013 Redistributable Package (x86)

4 Install qpst, click next



5 Select I accept the license agreement, $\ ,\$ then click next

Please read the following license agreement o	arefully.	
OPST(tm) Version 2 7		1.
Arol (out) Actoron 5.1		-
OUALCOMM Technologies Incorpo	rated	
Software License		1
Access to and use of this to and conditions of the cor place with Qualcomm Technolog its affiliated companies. Un prohibited. Additionally, s	ol are subject to the responding agreement(ries, Inc. or one or m authorized access or ression information su	terms (s) in ore of use is uch as
I accept the terms in the license agreement		Print
\bigcirc I do not accept the terms in the license agree	nent	
stallShield		

6 Do not modify the installation path, click next

🛃 QPST 2.7 - InstallShield Wizard	đ		×
Destination Folder Click Next to install to this folder, o	r click Change to install t	to a different folder.	Ľ
C:\Program Files (x86)\Q	ualcomm\QPST\		Change
InstallShield			
	< Back	Next >	Cancel

7 Select complete, Click next

🔁 QPST 2.7 - Instal	IShield Wizard			X
Setup Type Choose the setup	type that best suits	your needs.		さ
Please select a set	up type.			
Complete All Sp	program features w ace.)	ill <mark>be installed. (</mark> Req	uires the most disk	
Custom	ioose which program I be installed. Recom	features you want mended for advanc	installed and where ed users.	e they
InstallShield		Back	Next >	Cancel

8 Click Install

🔁 QPST 2.7 - InstallShield Wizard
Ready to Install the Program The wizard is ready to begin installation.
Click Install to begin the installation. If you want to review or change any of your installation settings, click Back. Click Cancel to exit the wizard.
InstallShield
< Back Install Cancel



\square . Install QDART

Document path:

https://www.asuswebstorage.com/navigate/s/680137D3EF584B43B8D5AEC449CB0A0BY or in Tuserhp.com

- 1 unzip qdart.win.4.8_installer_00053.111-20-17_10_57_30
- 2 Click Setup.exe



<u>____</u>

3	Click	next			
	122	0.000	22	100 30	

1 Car	Welcome to the Setup Wizard for QDART
	The Setup Wizard will install QDART on your computer. To continue, click Next.
	Recommended System Requirements for Full Installation
	 Desktop or laptop computer, Dual Core, 2 GHz Windows 7, Windows 8 2GB of RAM 4GB of hard drive space for full installation Microsoft .NET Framework 4.0 or above Microsoft MSXML4 & MSXML6 parsers A free serial I/O port or USB port, data cable QPST, Qualcomm USB host driver (delivered with QDART) or OEM USB host diagnostic Drivers
	MADNITH, This was support to supply shad by a supply law and

4 Tick the" I have read this notice", Click next

Notice Please read the following notice carefully.	· · · · · · · · · · · · · · · · · · ·
Confidential and Proprietary - Qualcor	mm Technologies, Inc. 🔺
NO PUBLIC DISCLOSURE PERMITTED: Please on public servers or websites to: <u>DocCtrlAgent@c</u> < <u>mailto:DocCtrlAgent@qualcomm.com></u> .	e report postings of this software <u>qualcomm.com</u>
RESTRICTED USE AND DISCLOSURE: This software contains confidential and proprietar used, copied, reproduced, modified or distributed, revealed in any manner, without the express writte	y information and is not to be in whole or in part, nor its contents n permission of Qualcomm
Technologies. Inc.	

5 Select complete, then click next

QUART - Inst	allation			
Setup Type				
Choose the se	up type that best si	iits your needs.		
Please select a	setup type.			
O Complete	1			
-	All program feature	es will be installed. (Requir	es the most disk sp	bace.)
@ Custom				
	Choose which proc	ram features you want in	stalled and where i	thev
	will be installed. Re	commended for advanced	l users.	
IALCOMM				
		< Back	Next >	Cancel

6 Select R&D, Click next

QSPR Workspace Selection	*
Determine which plug-ins to load and secur Pactory R&D	ity configuration to set by default when QSPR is starte Loads: - Global Variable View - QSPRAutomationPlugin - HTMLWindow - TestResults - XmlForDB - TPL3 - QSPRWinFormsChartsPlugin - Registration - TesterConfigTTD Security Feature Disabled
ALCOMM	< Back Next > Cancel

7 Do not modify the installation path, click next

JQDART - Installation			×
Destination Folder Click Next to install to this folder	, or dick Change to install t	o a different folder	
Install QDART to: C:\Program Files (x86)	\Qualcomm\QDART\		Change
Create shortcut on desktop			
QUALCOMM	< Back	Next >	Cancel

8 Click install

gDART - Installation	X
Ready to Install the Program The wizard is ready to begin installation.	с. С. р. С. С. р.
Click Install to begin the installation.	
If you want to review or change any of your installa exit the wizard.	tion settings, dick Back. Click Cancel to
QUALCOMM	

9 The installation process will pop up several interfaces that require driver installation. Select trust and install.



Department of the second seco	
The program features you selected are being installed. Please wait while the Setup Wizard installs QDART. This may take Windows 安全	several
您想安装这个设备软件吗? 名称: Qualcomm Incorporated 调制解调器 发布者: Qualcomm Technologies, Inc.	3
 ✓ 始终信任来自 "Qualcomm Technologies, Inc." 的软件(A)。 ✓ 您应仅从可信的发布者安装驱动程序软件。我如何确定哪些设备软件可以安全安装? 	
<back next=""></back>	Cancel
Windows 安全	e several
忽想安装这个设备软件吗? 全称: Qualcomm 网络适配器 发布者: Qualcomm Technologies, Inc. 図 始终信任来目 "Qualcomm Technologies Inc."	
● 您应仅从可信的发布者安装驱动程序软件。我如何确定哪些设备软件可以安全安装?	
N DOLK NEXL >	

1	B QDART - Installation			23
	Installing QDART The program features you selected are being installed.		0	 0
➡ Windows 安全	Please wait while the Setup Wizard installs QDART. This may	/ take severa	h	
您想安装这个设 名称: QUALCOM 发布者: Qualcon	备软件吗? IM nm Technologies, Inc.			
☑ 始终信任来自 "C 的软件(A)。	Qualcomm Technologies, Inc." 安装(I) 不至	史装(N)		
🕖 您应仅从可信的》	发布者安装驱动程序软件。我如何确定哪些设备软件可以安全安装?			
	< Back Next >		Cance	

B QDART - Installation	×
	Setup Wizard Completed
	The Setup Wizard has successfully installed QDART. Click Finish to exit the wizard.
	Launch Config Files EditorLaunch QDART Help
	< Back Finish Cancel

\equiv . Use QMSCT for image download

1. Execute "Program files ->QDART->QMSCT"



2. Click setup->configuration

	2	3	4
Connect A Unit	Connect A Unit	Connect A Unit	Connect A Unit
Stari Test	Start Test	Start Test	Start Test
128 Measage	Status Message	Status Massago	Status Message
	6	7	8
Connect A Unit	Connect A Unit	Connect A Unit	Connect A Unit
Start Test	Start Test	Start Test	Start Test
Message	Status Message	Status Message	Status Massage

- a. Select software download in Tuserhp.com
- b. Select test plan path:

..\WW-ZS620KL-80.02.237.32-FAC-for-QMSCT-eng-20180404122131-factory\WW-ZS620KL-80.02.237.32-FAC-for-QMSCT-eng-20180404122131-factory\ Draco_UFS_PROVISION_And_SW_download_FHLOADER.xtt

	-							a
Product Name	8x26		- -		Configuration	Software Down	load	2
echnology Common Co	nfiguration							b
Test Plan Path.	D:\HH\NPI\ZS62	20KL\Proload image\04-25	WW-ZS620KL-	-80.02.237.32-FAC-fo	r-QMSCT-eng-201804041	22131-factory	Bro	vse
Test Plan Timeout	500 +	XTT Timeout Offset	10 👻	Engine	QSPRGUI -	Technology	SWDL	-
echnology Specific Glo	aal Variable		11	Technology Specifi	c Configuration Quick Editor			
Name	Ý	/alue						
BINARY_IMAGE_FOLI	DER_PATH D	NHHNPINZS620KL/Prolo	ad imag				С	
					Binary Image Folder	Path:	Browse	1
							and the second se	
					D:\HHNPNZS620KL\Proto	ad image\04-25\	ww-	
					D:\HHNPNZS620KL\Prote ZS620KL-80.02.237.32-F/ eng-20180404122131-fac	ad image\04-25\ \C-lor-QMSCT- ory\WW-ZS620	WW- 1-80.02.237.32-	
				,	D:\HHNPNZS620KL\Prolo 2S620KL-80.02 237.32-FA eng-20180404122131-fac FAC-for-QMSCT-eng-2018	ad image\04-25\ AC-lor-QMSCT- ory\WW-ZS620+ 30404122131-far	WW- 180.02.237.32- tory	J
					D:HHANPI725620KL\Prote 25520KL-80.02.237.32-FJ eng-20180404122131-fac FAC-for-QMSCT-eng-2016	ad image104-25% AC-for-QMSCT- oxy%/V-72S8206 30404122131-fax	WW- 1_80.02.237.32- tory]
					D:1H1ANP125620KL\Prote 25520KL-80.00.257.32-F1 eng-20180404122131-fac FAC-for-QMSCT-eng-201	ad image104-251 AC-lor-QMSCT- ary1WW-ZS6201 80404122131-far	WW- 180.02.237.32- story]

c. Image folder path,

..\WW-ZS620KL-80.02.237.32-FAC-for-QMSCT-eng-20180404122131-factory\WW-ZS620KL-80.02.237.32-FAC-for-QMSCT-eng-20180404122131-factory\

- d. Click "station" to set com port
- e. Disable manual setup
- f. Click start setup process

(Please disconnect any devices you may already have connected before starting the setup)

Folder:	C:\Qualcor	mm\QMSCT\configurati	DN					
Product	Station	d						
ieneral								
Station Nam	.					🔽 Display Mes	isages	🗍 Auto Save Messages to File
C:\Qualcon	m\QMSCT\cor	liguration\SWDL.scfg		Browse_ Lang	uage English	 Message Filt 	er Setup	
Reast	Station Yield	Number of Panels	3 • 4 •	Totally ⊏ Same PerRow ⊽ GetS	: Color N From Unit Programmer			Add Remove Messages from "Message Windows" on left list is filtered
orts				Process	4		5	tatus
Panel		1st Port	-	SctupProcess	-	1		^
		3		Start Setup Process	Abort Siete	up Procesa		
3		53		Select Panel				
		54		Previous Pand	Next	Pand		
5		55		Port Setup Options				
6		56		r ⊂ Tport r Zport	E Manual E Phy Setup	Addr Net		
7		57	-	Part Delection Key Ward	EDownloade	Key (ODLoad x		
Option VID/PID					LEOWING		Scheduling	
VID	P	ID		-		1	Mode	
0500	90	106		Set VID PID to Ig	nore HW Serial Number	(Only for US8 2.0)	Fing And Play	ت (1993) بادہ) جمعہ جمعی سیال میں میں
0500	5 90	80		-			Start Unit Pi	ogrammer open stanup (Only QSPR)

- 3. Device press Vol_up + Vol_down + Power key into EDL mode,
- 4. Please connect device with OA via USB cable, after see the device manager will appear Qualcomm HS-USB QDLoader 9008 COM X,

▲ 装置管理員	- 0 :
檔案(F) 動作(A) 檢視(V) 說明(H)	
🗧 🔶 🗊 🖬 💭 🖳 😓 🗶 🏵	
✓ 🛔 X15244-NB2	
⇒ 🧝 DVD/CD-ROM 光碟機	
> 🦏 IDE ATA/ATAPI 控制器	
> 🏣 Intel(R) Dynamic Platform and Thermal Framework	
> 网络人性化介面装置	
> 圖 生物特徵辨識裝置	
> 💼 列印佇列	
> 🍙 存放控制器	
> 🔐 安全性裝置	
> 🏣 系統装置	
> ⑨ 相機	
> 🖬 音效、視訊及遊戲控制器	
> 1 音訊輸入與輸出	
> 🔲 處理器	
> ■ 軟體裝置	
> ● 通用序列匯流排控制器	
✓ ■ 連接埠 (COM 和 LPT)	
Qualcomm HS-USB QDLoader 9008 (COM3)	
> 🚺 滑鼠及其他指標裝置	
> 🙀 電池	
🤉 💷 竜腦	
> [] 監視器	
> 磁碟機	
、 🗇 细胞介面卡	

5. The ports & status field will detect com port

Folde	r:	C:\Qualcomm\QMSCT\configuration		
Produ	ct	Station		
ienera	l.			
Statio	on Name:		🖾 Display Mensages	T Auto Save Messages to File
C:\0	halcom	VQMSCT\configuration\SWDL.scfg	Browne Language English * Message Filter Setup	
				· ·
		8	* Totally E Same Color	Add Remove
0	Reset Sta	Ibon Yield Number of Panels	Ben Bana F Gat SN From Unit Programmy	Messages from "Message
-				Windows" on left list is filtered
onta			Process	Status
	Panel	Ist Port	SetupProcess	
	1	3	Start Setup Process Abort Setup Process	Port Into Received: 3 Port detected to be 3
	2	52	Select Page	
	3	53	Previous Panel Next Panel	
1	4	54		
	5	55	-Port Setup Options	
	6	56	- C Iport C 2port C Manual C Phy Add C Net setup C Setup C Mode C Mode	
	7	57	Port Detection Key Word: EDownloaderKey (QDL pad *)	
Option	2.000			1
VID/	PID	000	Scheduling Mode	
	05CE	9006	Sat VID BID to Jacons Kid Second Number (Only for USP 2 0) Plug And P	lay 🔹
1	0506	9008	Sec vio no to ignore niv senar number (Only to 036 20)	(Programmer Upon Startup (Only QSPR)
_	5565			

6. Select "Product" then click "save"

	-R								
General									
Product Name	21/26		-			Configuration	Seftware Dow	nload	
Technology Common Co	ntiguration								
Test Plan Path	DAHHANP	VZS620KL\Proload mage	04-25\WW-Z	5620KL-80.02	237.32-FAC-for-QN	ISC T-eng-2018040412	22131-factory*		Browse_
Test Plan Timerul	500	* XTT Timenat Off	bet [10	-	Engine 1056	POGUI -	Technology	SWOL	-
Tankadan Onuita Cid	Contraction of the	and stored to be a set of the set	1.4	Test	and and the Constant of Constant			Jourse	
Leculosoft abecute are					norogy opecine con	agaaaan sack cata			
Nome		Value	10	100					
Name BINARY_IMAGE_FOLD	DER_PATH	DAHHANPAZS620KL	VProload imag						
Name BINARY_DMAGE_FOLD	DER_PATH	DAHHANPT725620KL	AProtoad imag		в	nary Image Folder	Path	Browse	
Nemo BINARY_IMAGE_FOLD	DER_PATH	D-M-HNNPT-25520KL	VProtoact imag		Bi	inary Image Folder HHNP/25200 Poly	Path ni mari (M-29)	Browne	
Nama BINARY_IMAGE_POLI	DER_PATH	DOURDONPT/25620KL	Woload imag		Bi 01 23	inary Image Folder HHNP/255200 Proto 620K0 - 40.02 237 32-FA - 20180401122111-fact	Path ad imagel04-29/ aretWeb-798200	Browse Wel- 0 -80 02 237 32-	
Nams BINARY_DANGE_FOLD	DER FATH	Velue DINHENNETUZSEZOKI	VProload imag		Bi 25 75	inary Image Folder HHMPA2SE200, Proba 2000, 40 02 237 32-64 2/2018040122131-64 C 4a-GMSCT-org-2018	Path of image/04-29 C-for-QMSCT- ory/Wei-29620 0404122131-fac	Browse WW- Q-80 02,237,32- tory	
Name BINARY_IMAGE_FOLI	DER_PATH	Velue DINHENNETUZSEZOKI	AProtoad imag		Bi D1 253 73	inary Image Folder HHNP/L2SE200.9volu 620Ki.40.02.237.32-FA 220180001122131-lock 6.4er-QMSCT-org-2018	Path: ad image/04-25 C-for-QMSCT- ary/Wei-25520 0404122131-fac	Browse WW- Q80 02 237 32- they	
Name BINARY IMAGE FOLD	DER_PATH	Oshinya a sayara	Wrokoad imag		Bi 273 78	inary Image Folder HHMPK2SE200. (Pola 6200. 40.02.237.32-Fa 22018004122131-fact 6.4ar QMSCT-ang-2018	Path of image/04-25 C-for-QMSCT- or/WW-256200 0404122131-for	Browse WW- Q-80 02 237 32- thory	
Name BIRARY DUAGE FOLD	DER_PATH	D-VHNPT/256200	AProfoad imag		Bi 25 73	innry Image Folder IHNAPAZSIZIOL (* Youk 2001 – 300 237 32-FA g-20180001122131-lact & for GMSCT-eng-2018	Path od imagel04-25% c-for-QMSCT- ordWA-258200 0404122131-for	Browne WW- Q80 02 237 32- ttory	
Name BINARY DAAGE FOLT	DER_PATH	Charles	AProfoad imag		Bi 253 75	innry Image Folder HMMPAZSIZIQU (Pvba 2008-100 (237 32-Fa 27018000122131-last 2-0018000122131-last 2-for QMSCT-ong-2018	Path od imagel04-259 C-for-QMSCT- orytMA-258200 0404122131-for	Browne Wei- GR0 02 237 32- tory	•

- 7. Please re-plug the USB cable
- 8. The program will auto download image

ion D. WHENPEZ S670KUPhalond imamia	the state of the s		
	2	3	
Running	Connect A Unit	Connect A Unit	Connect A Unit
Stop Texting rescage	Status Message	Statut Message	Status Meesage
	·	, <u></u>	
Conserved & Linet	6		8
A STREET & LOUI	Connect & One	- Continue & Cont	COUNCER DIN
Start Test	StartTest	Start Test	Start Test
resign	Status Hensage	Salut Message	Safut Message
	, e a ⊠ ¢ a ¢ <mark>r</mark>	•	2 ∧ ≈ 4 + 0 7100 2 ∧ ≈ 4 + 0 2100
Help Help M. D Bronker A. D Bronker D Statistical Statistics D Statis			
nety sety set Dealand In: D 1499/H72562061/Holead (inspit)	C 21 2 3 2 4 C to CRECT or 2010	00112121 conjubri 25000, 800 231 51 F/C ka 00801 1217 monipubri 25000, 800 231 51 F/C ka 00801 1217 monipubri 25000, 800 231 31 F/C ka 00801 mo	م المراجع الم المراجع المراجع ا المراجع المراجع ال المراجع المراجع
reg terg ter Detected the D VHWHY2550K VPushed insigning ter D VHWHY2550K VPushed insigning PASS	Connect A Unit	60112721 conjubri 25000, 601221 St P/C to Q405C1 vo 12721 doby/stri 55000, 601221 St P/C to Q405C1 vo 1281 doby/stri 55000, 601221 3 (P/C to Q405C1 vo 1281 doby/stri 55000) (P/C to Q405C1 vo 1281 doby/str	A Connect A Unit
Image: Processing of the second sec	20104-25296-10 02 233 324 AC-be-QHECT-working 4.9004-25296-10 02 233 324 AC-be-QHECT-working 4.9004-25296-10 02 233 324 AC-be-QHECT-working 2.0005-02 AU-02 Connect A Unit	Rei 1271 de conjetel 25000, 4912 251 251 / 2 4 4 4945 d 1271 de conjetel 25000, 4912 251 251 / 2 4 4 4915 d 1271 de conjetel 25001, 4912 272 / 12 6 4 4915 d 13 Cennect A Unit	الله المراجع الم المراجع المراجع ا مراجع المراجع ا مراجع المراجع ال المراجع المراجع ا مراجع المراجع الم
CD EN DD CD CD EN DD CD	Connect A Unit	Ref 1211 Second Well 2510 St PAC in operations 1221 Second Well 221 Seco	Connect A Unit
	Connect A Unit	Rel 1271 Complete / SCOOL 4912 231 23 47 C to 4945C1 2271 Marry Met / SCOOL 4912 231 23 47 C to 4945C1 2371 Marry Met / SCOOL 4912 237 23 47 C to 4945C1 we 3 C connect A Unit Start Test Refine Marriage	Connect A Unit Stary Teel Stary T
Territoria Territ	Contract A Units	Rel 1211 Start / SCOOL 40 52 21/ St # A C 4+ QARCT 121 Starty (Her / SCOOL 40 52 21/ St # A C 4+ QARCT + 3 Connect A Unit Start Test Home (Hereage	ConnectA Unit Service
	Connect A Unit	BH12712 Connect A Unit.	Connect A Unit
	Connect A Unit	Bel 1271 21 complete / 55000, 4510 221 53 F/A Ser 4(451) 221 53 F/A Ser 4(451) 221 53 F/A Ser 4(451) 421 221 23 F/A Ser 4(451) 421 421 421 421 421 421 421 421 421 421	Connect A Unit Bata Manageria Connect A Unit Connect A Unit Sary Teal Connect A Unit Sary Teal Connect A Unit Sary Teal Sary Tean Sary Teal Sary Teal Sary Teal Sary Teal Sary T

9. Please remove USB cable and reboot the device Q&A

Debug: Sahara Fail:QSaharaServer Fail:Process fail Please re-enter EDL mode